



# NewTechWood Screening Installation Guide

v20180724AU



**IMPORTANT:**  
**Read All Sections Before You Start**

For the most up to date information, please visit our website @ [www.newtechwood.com.au](http://www.newtechwood.com.au)

**NewTechWood screening profiles are designed for decorative and privacy screening applications only.**

They are **NOT RECOMMENDED TO BE USED FOR THE FOLLOWING:**

- X Pool or security fencing
- X Safety Balustrading
- X Structural Elements
- X Applied directly to solid surfaces

### **Expansion & Contraction:**

NewTechWood Screening will expand and contract in length with changes in temperature, due to the nature of the composite material. This is normal behaviour of any wood plastic composite and is not a product fault. It is important to take this into proper consideration before installing.

The amount of expansion and contraction you experience is dependent on several different factors including:

- Temperature at the time of installation.
- Length of board. The longer the length the more expansion; shorter the length, less expansion.

### **Fixing to Timber:**

1. Stainless Steel 8g x 50mm or 10g x 65mm composite screws are recommended for fixing NewTechWood Screening profiles to timber posts..
2. Pre-drill and countersink all holes to avoid mushrooming. It is recommended to drill holes slightly larger than the screw to allow for any expansion and contraction.

### **Fixing to Metal**

1. Stainless Steel 10g x 40mm self-tapping screws are recommended when fixing NewTechWood Screening profiles to metal posts.
2. Pre-drill and countersink all holes to avoid mushrooming. It is recommended to drill holes slightly larger than the screw to allow for any expansion and contraction.

### **Thermal Deflection**

Due to the nature of wood plastic composites, NewTechWood Screening profiles may show a slight deflection between posts when in direct sunlight.

This is generally caused by heat exposure to one side of a board as opposed to the other. The extent to which this occurs is dependent on several factors including ambient air temperature. This phenomenon is not considered a product fault.

**NEWTECHWOOD SCREENING SPAN TABLE**

<b>Profile</b>	<b>US36 70mm x 17mm</b>	<b>US06 138mm x 15mm</b>	<b>US07 138mm x 23mm</b>	<b>UB01 56mm x 32mm</b>	<b>UH17 60mm x 42mm</b>	<b>UH25 100mm x 52mm</b>
<b>Single centre to centre maximum span (horizontal installation)</b>	900mm	800mm	900mm	900mm	1200mm	1350mm
<b>Continuous centre to centre maximum span (horizontal installation)</b>	900mm	800mm	1200mm	1200mm	1200mm	1350mm
<b>Maximum span between rails (vertical installation)</b>	900mm	800mm	1200mm	1200mm	1350mm	1500mm
<b>Minimum distance from edge of boards for fastening</b>	15mm	15mm	15mm	15mm	15mm	15mm
<b>Number of fasteners per fixing point</b>	2	2	2	1	1	2
<b>Minimum clearance from rear wall</b>	30mm	30mm	30mm	30mm	30mm	30mm
<b>Minimum gap spacing between boards</b>	2mm	2mm	2mm	5mm	5mm	5mm
<b>Minimum ground clearance</b>	50mm	50mm	50mm	50mm	50mm	50mm
<b>Minimum clearance from end of board to fixed structure</b>	5mm	5mm	5mm	5mm	5mm	5mm
<b>Minimum end to end butt joint</b>	3mm	3mm	3mm	3mm	3mm	3mm
<b>Maximum overhang</b>	25mm	25mm	40mm	40mm	50mm	50mm





# NewTechWood Screening Installation Guide

v20180724AU

©2017 Distributed in Australia by:  
Urban Direct Wholesale Pty Ltd  
Unit 1, 5 Erceg Road  
Yangebup, WA 6164, Western Australia  
Email: [info@urbandirectwholesale.com.au](mailto:info@urbandirectwholesale.com.au)

NewTechWood is a registered trademark of Huidong Meixin Plastic Lumber Products Manufacturing Co., Ltd. To obtain a copy of the most current version of this installation guide, visit us online at [www.newtechwood.com.au](http://www.newtechwood.com.au)

